



Detroit Speed, Inc.
RS Electric Headlight Door Kit
 1968 Camaro
 P/N: 122004

Thank you for your purchase of Detroit Speed's RS Headlight Door Kit. This kit replaces the stock vacuum actuators on an RS headlamp equipped 1968 Camaro. When installed, this kit will operate the headlight doors smoothly and reliably. The complicated, failure prone, and bulky vacuum accessories can all be eliminated. Vehicles with large cams with low vacuum signals will also benefit from this system since they are electronically controlled.




Figure 1

Item	QTY	Description
1	1	LH Actuator w/ Bracket and Linkage
2	1	RH Actuator w/ Bracket and Linkage
3	1	Headlight Door Control Module w/ Bracket
4	1	Harness Assembly
5	3	Rubber Grommet
6	10	Nylon Wire Ties
7	1	Instructions/Inner Fender Template

Many convenience features are integrated into this system. When the headlight switch is pulled to the “park” position, the park lamps illuminate. The headlights stay off and the headlight doors remain closed. When the switch is pulled to the “headlamps” position, the park lights stay on, the headlight doors open, and the headlamps illuminate. When the switch is pushed back to the “park” position, the headlamps turn off, but the headlamp doors remain open. This is useful to clean or service the headlamps since the doors will be open and the lenses cool. When switched to the “off” position, the park lights go out and the headlight doors close.

The module that is included with the RS Electric Headlight Door Kit has a unique integrated failsafe protection mode. The module is designed to protect itself from damage due to a short circuit in your wiring system. If a short exists, the module will click continuously. This means a short has been detected and the module has entered into its fail safe mode. For the system to operate again, correction of the short circuit is required followed by resetting the module. To reset the module, remove the fuse from the main power wire for 10 seconds and then reinstall the fuse. If the clicking reoccurs, the short has not been repaired and needs further investigation.

The actuators are pressure sensitive to reduce the chance of personal injury or damage to the vehicle in the event that something is caught in the door during operation. If the door comes in contact with a foreign object, it will stop its operation. The lights will need to be cycled on and off to reset the mechanism. **NOTE: The pitman arms on the actuators will not be able to be moved by hand as that could cause permanent damage to the actuators.** The pitman arms are clocked in the correct position for installation at Detroit Speed and will cycle closed once power is introduced to the system.

Detroit Speed has gone to great lengths to provide you with the highest quality, best engineered product available with straightforward installation requiring minimal modification to your vehicle.

IMPORTANT: This kit is designed to work with properly installed and adjusted RS headlight doors. This system will not work correctly with doors that do not have the stops adjusted properly. The doors must open and close without binding or resistance. Because the system is pressure sensitive, binding or sticking RS door assemblies will cause the actuators to stop prematurely. Detroit Speed suggests lubricating all pivot points. Make sure that the main pivot shaft and the bellcrank are not overtightened.

The battery must be disconnected before starting the installation.

I. Mount the RS headlight module

1. Locate brake pedal support bracket under the driver's side dash spanning from the brake pedal assembly to the steering column support attachment. Mock up the module and mounting plate and locate the bolt holes on support bracket with a marker or scribe (Figure 2 on the next page). The module should be positioned towards the driver's side.



Figure 2 - Locating the Holes

2. Using the marks located in the previous step, drill two 5/16" diameter holes in the support bracket. Slide the two included U-nuts over the drilled holes. One U-nut is larger than the other. This is to compensate for the angle on the support bracket. Make sure the holes are drilled so that the U-nuts can be properly installed. Attach the module mounting plate to the support bracket using the two included black oxide 1/4" diameter bolts and washers. The finished, mounted module assembly is shown below in Figure 3.



Figure 3 - Module Mounted in Place

II. Install the Module Wiring

1. Remove the headlight switch from the dash. This can be simplified by removing the Astro Vent below the switch (Figure 4).



Figure 4 – Removing the Astro Vent

2. The headlamp switch can then be removed from the dash through this opening (Fig. 5).



Figure 5 – Accessing the Headlamp Switch

3. Remove the connector from the headlight switch. Locate and mark the blue wire (Figure 6). Remove the terminal from the connector housing using a terminal removal tool or a small flat blade screwdriver. The blue wire is the 12 volt headlamp feed.




Figure 6 – Locating the Blue Wire

4. Slide the included black male connector over the blue wire terminal which was just removed from headlight harness connector (Figure 7). Connect the stock blue wire to white female connector (blue wire) on the harness assembly (Figure 8).




Figure 7 – Install Black Connector




Figure 8 – Harness Assembly

5. Now, locate the blue and brown wires on the supplied harness assembly. Slide the blue wire/female terminal (Figure 8 above) into the cavity in the headlight switch connector where you removed the stock blue wire. Slide the female terminal on the brown wire (Figure 8 above) into the empty cavity shown in the picture (Figure 9 on the next page).





Figure 9 – Locating the Brown and Blue Wires

6. If you are using an aftermarket wiring harness, this terminal may be filled. In this event, the brown wire must be spliced into the park lamp signal wire. Connect the black ground wire to the ground stud under the dash near the parking brake. **NOTE:** DO NOT attach the red positive lead to a constant 12V power source at this time. This will be done in a later step.



NOTE: The 2 leads for the parking lamp (numbered 3 and 5) will need to be bridged together in order for this kit to work correctly (Figure 10 on the next page). If your headlight switch does not have a bridge you will need to jump the 2 leads together.




Figure 10 - Headlight Switch

III. Install the Actuator Harness

1. Drill a 1-1/8" diameter hole near the firewall bulkhead using a Uni-bit or drill bit to pass the headlight motor connectors through the firewall. Use the included firewall grommet to protect the wiring.
2. Route the wires along the inner fender well along the stock headlight harness toward the front of the vehicle. Drill a 1-1/8" diameter hole behind each headlight bucket to pass the harness leads through. We suggest drilling the hole adjacent to the turn signal wire grommet. Insert the supplied rubber grommets and feed the two wires through toward the actuator. The yellow and orange wires should pass through the driver's side inner wheelhouse. Route the green and purple wires along the factory harness underneath the core support to the passenger side inner wheelhouse. Pass the green and purple wires through the grommet. Secure the harness with the supplied nylon ties.

IV. Install Actuators and Linkage

NOTE: A template has been attached on page 11 of the instructions to assist you in locating where to cut holes in your stock inner fenders to install the RS headlight assemblies in vehicles that were not originally RS headlight equipped. Some aftermarket inner fenders may also need this template to locate the holes for the RS headlight assemblies. Cut the template from the sheet and align it as described on the template. The template can be used on both sides by flipping it over. After cutting out the template, align it to the front edge of the inner fender and the existing holes. Mark the new holes on the inner fender and cut out the appropriate holes.

1. Remove the battery and battery tray.
2. Under the vehicle, if the headlight door vacuum actuator system is still installed, remove it from the vehicle. The vacuum tanks, actuators, hoses and valves will not be needed.
3. **NOTE: If there is an over-center spring installed on the bellcrank assembly, it must be removed.** It is located behind the headlight bucket. The headlight must be removed to gain access to the spring. Right angle pliers and a screwdriver will be helpful to remove the spring. Be sure to wear proper eye protection. If the spring cannot be removed, the headlight bucket assembly will have to be removed from the car.

4. Locate the two bolts on the passenger side that attach the inner wheelhouse to the core support underneath the front fender area (Figure 11).



Figure 11 – Location of Core Support Bolts

5. Using a 1/2" socket, remove these two bolts and position the actuator and bracket assembly. The actuator should point forward and the pitman arm should be on the bottom side of the bracket. The holes are slotted so that the actuator assembly can be aligned with the bellcrank of the RS headlight assembly. Reinstall the two bolts using a 1/2" wrench and socket to attach the actuator to the vehicle. **NOTE:** Position the actuator/bracket so that the pitman arm can pass underneath the splash guard bracket without contact. If you plan on using the splash guard you will need to trim it as necessary to clear the pitman arm.
6. Insert one of the two supplied nylon bushings into the bellcrank of the RS headlight assembly from the bottom (Figure 12).



Figure 12– Installing Bushing in Pitman Arm

7. Install the linkage to connect the actuator to the bellcrank. Install with the supplied washers and locknut using a 3/8" and 7/16" wrench (Figure 13 on the next page). If the linkage does not reach the bellcrank, reposition the headlight door until they can be assembled. **NOTE: Do not attempt to move the pitman arms on the actuators by hand to attach the linkage as this could cause permanent damage to the actuators.**



Figure 13 – Connect Linkage to Actuators

8. Connect the harness to the actuators and make sure the wires are routed away from moving parts or sharp edges. Use the supplied nylon wire ties to secure the harness.
9. The driver's side and passenger's side actuator installation is the same.
10. Reinstall the battery and tray.

V. Powering the System

1. Attach a 12V constant power source to the module by installing the red wire from the new harness into an open slot on the fuse block labeled "battery". Make sure the 10 amp fuse is installed in between the power source and the module.
2. Connect the black wire with the ring terminal on the new headlight harness to a suitable ground. Make sure to remove any paint or corrosion to ensure that a good ground connection is made.
3. Connect the new headlight harness to the module. The clear connector on the harness will plug into the black connector on the module. The black connector on the harness will plug into the clear connector on the module. Verify this by checking that the wire colors on the harness match the wire colors on the module pigtails.
4. Before powering the system, double-check all of the wiring connections for continuity using a multi-meter. Incorrect wiring can cause serious damage to the system.
5. Reconnect the battery. The system will cycle at this point and the doors should be in the closed position.
6. Once the system has cycled, check the operation of the system by turning the headlamps on and off. If the system is not operating, check all of your wiring connections again and refer to the troubleshooting guide at the end of these instructions. **NOTE:** If you are still having problems, one solution is to bypass the fuse block and run the power and ground wires directly to the battery.

VI. Installation Complete

If you have any questions before or during the installation of this product please contact Detroit Speed Inc. at tech@detroitsspeed.com or 704.662.3272

Legal Disclaimer: Detroit Speed, Inc. is not liable for personal, property, legal, or financial damages from the use or misuse of any product we sell. The purchaser is solely responsible for the safety and performance of these products. No warranty is expressed or implied.

RS Headlight Troubleshooting

After all connections are made, connect the battery. The doors should go through a "power up" cycle. During this cycle, the doors will close. Anytime the current source to the module is disconnected and reconnected, the doors will go through the "power up" cycle. The module features a failsafe protection to protect the module from being shorted out. If a short exists, the module will beep and is followed by a series of clicks. This means a short has been detected and the module has entered into its fail safe mode. For the system to operate again, correction of the short circuit is required followed by resetting the module. To reset the module, remove the fuse from the main power wire for 10 seconds and then reinstall the fuse. If the clicking reoccurs, the short has not been repaired and needs further investigation. The following chart shows the expected voltages at the module input during typical operation. Use this to troubleshoot the wiring installation and headlight switch operation.

Headlight Switch Position	Wire Color				Door Operation	Light Operation
	Red	Black	Brown	Blue		
Off	+ 12 V	Ground (- 12V)	0 V	0 V	None	None
Park	+ 12 V	Ground (- 12V)	12 V	0 V	None	Park
Headlight	+ 12 V	Ground (- 12V)	12 V	12 V	Door Opens	Park/Headlights
Park (after headlights on)	+ 12 V	Ground (- 12V)	12V	0 V	None (Door remains open w/headlights off)	Park
Off	+ 12 V	Ground (- 12V)	0 V	0 V	Door Closes	None


Condition

Cause

Module clicks continuously.	The module has entered into its failsafe mode. The module enters into this mode when it detects a short in the system. To correct, determine and repair the short that exists in the system. To return the module to its normal function, remove the 10 amp fuse for 10 seconds and reinstall the fuse. The system should go through its "power up" cycle. If it does not or the clicking continues, a short still exists in the vehicles electrical system and requires further investigation.
Doors only open or close partially.	Most issues with door operation are due to headlight door assemblies that have too much resistance, binding, or are out of adjustment. To check for correct operation of the module and actuators, disconnect the linkages from the pitman arms. With nothing attached to the motor pitman arm, have another person cycle the switch from off, to park, to headlight, and then back to off. The actuators should turn approximately one complete revolution in one direction, stop, and then turn one revolution in the opposite direction. If the actuators operate as described, intermittent problems are most likely due to doors that have too much resistance opening and/or closing.
One door opens faster/slower than the other.	One door has more/less resistance than the other. Lubricate pivot points and adjust the tension of fasteners at pivots points.
Doors do not operate at all.	Make sure the battery voltage is over 11.5 V. A low battery condition can result in inoperable doors. Check all connections. Make sure fuse is not blown and doors are not binding.
One or both doors close when the headlight switch is turned on. Door(s) open when the headlight switch is turned off.	On the driver's side, make sure the yellow wire is inserted into cavity "2" and the orange wire into cavity "1" of the connector body. The purple wire should be inserted into cavity "2" and the green wire into cavity "1" of the connector body for the passenger side. If the wires are terminated properly and the problem still exists, reversing the wires on the offending actuator(s) will solve the problem.
Doors do not go through "power up" cycle.	Check voltages at red, black, blue, and brown wires as described in above chart. If voltages are consistent with the chart, try disconnecting and reconnecting the red wire. If the doors do not operate or do not attempt to operate at this point, double check that the actuator harness is plugged into the module and the actuators. Check continuity between the actuator wires at the module pigtail and at the actuator connector.

Module Connector Pin-out (back of connector)


Red Wire	Constant 12V Battery Voltage
Black Wire	Ground
Brown Wire	Park Lamp Feed
Blue Wire	Headlight Feed
Orange Wire	LH Actuator +
Yellow Wire	LH Actuator -
Green Wire	RH Actuator +
Purple Wire	RH Actuator -



*looking from back side of connector

* If none of these suggestions solve your particular issue, please call Detroit Speed at (704) 662-3272.

Cut this template from
the cross-hatched area.



UNLESS OTHERWISE SPECIFIED:

DIMENSIONS ARE IN INCHES
TOLERANCES:
FRACTIONAL: $\pm 1/64$
ANGULAR: MACH $\pm .5^\circ$, BEND $\pm 1^\circ$
TWO PLACE DECIMAL: $\pm .01$
THREE PLACE DECIMAL: $\pm .005$

INTERPRET GEOMETRIC
TOLERANCING PER:
ASME Y14.5M-1994

MATERIAL

FINISH

SCALE: 1:1

DO NOT SCALE DRAWING



PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING
IS THE SOLE PROPERTY OF DETROIT SPEED &
ENGINEERING. ANY REPRODUCTION IN PART OR
AS A WHOLE WITHOUT THE WRITTEN PERMISSION
OF DETROIT SPEED & ENGINEERING IS PROHIBITED.

DRAWN BY
CSM
DATE
12/15/08

TITLE

RS Inner Fender Template

APPLICATION(S)

1968 Camaro RS Conversion

SIZE DWG. NO.

A 9912128

REV

P-00

PRINTED ON 3/17/2009

SHEET 1 OF 1

5

4

3

2

1