

## INSTALLATION INSTRUCTIONS

Thank you for your purchase of this vertical quarter glass run channel. We can proudly claim that all parts, materials, and assembly of this channel set are made in the U.S.A.

We know this is not a perfect original or reproduction channel, but it will keep weather and noise out and finally allow you the ability to use your rear window.

The installation instructions are for information only. After several installs, we found that either one will work. These channels are made with aluminum and will not rust, but will need to be painted black, if you want it as the original.

### STEP 1:

Clean the inside pillar and remove all old material and felt, then pre-fit the channel.

### STEP 2:

There are no pre-drilled holes in these channels.

We (highly) recommend installing with a 2-part structural adhesive or 3M if cleaned properly.

If installing screws, we recommend you drill and countersink one hole at the highest and at the lowest part of the channel (see picture below). This is to prevent the plastic guide, on the quarter glass, from catching on the screw when rolling your window up or down.

### STEP 3:

Spray or lightly grease the forward channel to allow the plastic guide to move smoothly. Once in and rolled up, leave the window in the up position. As with all new weather-strip, this will be a tight fit until the material conforms to the glass.



**DRILL NO LARGER THAN 1/8"  
PREFERABLY 1/16"**