



Installation Instructions For 70100101 Rear Shock Tower Brace

1. In order to install the rear shock tower brace, you will need to make room by jacking up the rear of the vehicle. Make sure to install a set of jack stands to sturdy the vehicle. Block the front wheels!
2. If your jack stands are under the chassis, you'll need to support the axle with additional jack stands or the jack for the next step or the axle will drop.
3. Remove the upper shock bolts, two per shock.
4. Carefully slide the brace on top of the frame between the chassis and the floor.
5. Using the supplied hardware, slide the bolts through the shock, then the chassis, then the brace. Carefully install the nuts on top. Note: We supply $\frac{3}{8}$ " hardware which may require drilling out the holes on the frame.
6. Torque bolts to 25-30 ft. lbs.
7. Carefully jack the car up and remove jackstands, then place the car on the ground.
8. Enjoy!

PROPER INSTALLATION IS CRUCIAL!

Designed, Engineered, and Manufactured In The USA!