



## **Installation Instructions For 70100201 Front Brace**

1. In order to install the front sway bar brace, you will need to make room by jacking up the front of the vehicle. Make sure to install a set of jack stands to sturdy the vehicle. Block the wheels!
2. Remove the front sway bar bolts on both sway bar mounts ONLY.
3. Loosen but don't remove the rear sway bar mounting bolts.
4. Slide the brace between the sway bar mounts and the frame.
5. Reinstall the front sway bar bolts.
6. Torque all bolts to 25-30 ft. lbs.
7. Carefully jack the car up and remove jackstands, then place the car on the ground.
8. Enjoy!

---

***PROPER INSTALLATION IS CRUCIAL!***

**Designed, Engineered, and Manufactured In The USA!**